Assembly Instruction Sheet #IS-9966P23 For Style 9966P23

equines: Falthead ecrevicher, Philips screwicher, pilons, who culture, who ethypers, electrical tape, eafely glass, sures: (5) E25 Candelstan Base Bube 60W Maximum (Not Include).

Id Assembly Time: 10-20minutes

sect all parts before beginning installation. Check peckage content lat and diagrams below to be sure all parts Insing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for

Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fluture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect that is from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool



