

Assembly Instruction Sheet #IS-QS8391P24 For Style QS8391P24

Tools Required: Flathead screwdriver, Philips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (12) G9 40W Incandescents (Not Included).


Estimated Assembly Time: 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

⚠ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.


Package Contents



1 Fixture Body x1

Hardware Contents

PART	DESCRIPTION	QUANTITY
B8	Wire nut	2pcs
CC	Outlet Box Screw	2pcs



STEP 1- Release Crossbar from Ceiling Canopy.




Figure 1

STEP 2 - Attach Mounting bracket to Outlet Box




Figure 2

STEP 3 - Wire Connections

A. Use standard wire connections to make all wire connections. Twist connectors and wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.




Figure 3

STEP 4 - Install Ceiling Canopy to Ceiling




Figure 4

STEP 5 - Install Bulbs.




Figure 5